

ICEE MAKER®

AGES 6+

READ ALL INSTRUCTIONS CAREFULLY PRIOR TO ASSEMBLING AND USING YOUR ICEE MAKER. PARENTAL SUPERVISION IS RECOMMENDED.

NOTE: The ICEE Maker performs better and creates better end results when the drink used is cold and contains sugar. Drinks with a low sugar content, diet drinks and drinking water, do not work.

What you need from home

- 1 tablespoon lukewarm water • oven mitts or towel
- 1 spoon for removing any leftover ICEE® from ICEE® Chamber
- table salt - enough to fill measuring cup provided
- After step 5, remove from the refrigerator**
- ice cubes - enough to fill the ice canister
- 1 can of soda pop or 366 ml of fruit punch or juices, high in sugar

MAKING YOUR ICEE® [after washing all parts]








CLEANING YOUR ICEE MAKER [information on reverse side]

Cleaning your ICEE Maker [steps 1 to 8]

It is very important to wash your ICEE Maker after each use. If not, soda pop or juice products will dry and cause damage to the unit. When cleaning the unit, thoroughly wash and rinse all areas in contact with food products. Thoroughly dry all parts before assembly.

NOTE: DO NOT PLACE YOUR ICEE MAKER IN A DISHWASHER. THE ICEE MAKER AND ITS PARTS ARE NOT DISHWASHER OR MICROWAVE SAFE. BE CAREFUL NOT TO MISPLACE ANY PARTS



PROBLEM	SOLUTION
Ice Mixer does not turn properly	The Ice Mixer has come off the button. Using a towel or oven mitts to protect your hands, remove the metal ice Canister, open the Ice Canister Lid and gently rotate the Ice Mixer by hand to move the ice out of the way. Make sure the Ice Mixer is placed back on the button. Replace the metal ice Canister back in the SQUISHEE Chamber.
Metal Ice Canister Lid does not seal properly	Remove just enough ice from the metal Ice Canister to close the lid. It may be filled too high.
Consistency of SQUISHEE is very liquid	<ul style="list-style-type: none"> Make sure that proper amounts of luke warm water, salt and ice were put inside the metal Ice Canister. Make sure that you use a cold drink from the refrigerator for best results. Diet drinks or drinks with low sugar content will not freeze to a satisfactory level. Use regular soda pop or a non-diet fruit punch. Make sure to turn the crank for 4 minutes before trying to dispense.
Metal Ice Canister and Auger freeze together	Have a parent remove the Ice Canister and Auger by holding the unit with a towel. Hold under warm water until the ice crystals disappear. Repeat SQUISHEE making process using a drink with a higher sugar content or reduce the amount of salt.
Difficulty turning the Crank	Try rotating the Crank from a clockwise to a counter clockwise direction and back to a clockwise direction. This will reduce any blockage that may occur. Once the liquid becomes frozen, the friction will automatically increase.

DOES NOT WORK WITH SUGARFREE OR DIET BEVERAGES.

© 2003 SPIN MASTER LTD. All Rights Reserved. SPIN MASTER LTD., 450 Front Street West, Toronto, ON M5V 1B6, Canada
Ph.: 1-800-622-8339 Fax: 416-364-8005 Web: www.spinmaster.com Email: toys@spinmaster.com

©ICEE IS A FEDERALLY REGISTERED TRADEMARK. THE END RESULTS FROM THIS TOY ARE NOT AN EXACT REPRESENTATION OF A REAL ICEE®.

Conforms to safety standards ASTM F963-96a, EN71. Products and colors may vary. MADE IN CHINA.

